



General Details

Assessor	Samuel Prieto Ayllon
Assessment Date	02/07/2025
Assigned Reviewer	Samuel Prieto Ayllon
Next Review Date	02/07/2026

Signed Off By	Oraib AlKheetanRojas
Signed Off On	19/05/2026
Sign Off Comments	

Operation Assessed	3D Hand-held Scanner - Creaform Go!SCAN 3D Operation
--------------------	--

Associated with specific area

 Basement 2

 B2 029 (Robotics Lab)

 CTP

Description of work area and/or activity assessed

This assessment covers the routine use of the handheld Creaform Go!SCAN 3D structured-light scanner for research-grade digitisation of parts. The operator powers the scanner from a laptop USB 3.0 port or its 18 V adaptor and sweeps it around stationary objects while live data are streamed to VXelements on a workstation. Typical tasks include reverse engineering, quality inspection, and generating meshes for additive manufacturing in a clean, indoor environment.

Reason for Risk Assessment

To document and control any health, safety, and equipment-damage risks introduced by actively using the Go!SCAN 3D in research activities.

Overall Current Risk

Low Risk



Average Number of Persons Affected

2

 Employees

2

 Students

Current Rating	Hazard Information	Task Status
Low Risk	⚠️ Electricity Contact with or damage to the USB 3.0 lead or 18 V power adaptor could expose conductors carrying Safety Extra-Low Voltage (SELV) DC, leading to mild electric shock, short circuit, or spark during installation, relocation, or maintenance. Although the scanner is CE-marked for the Low-Voltage Directive, accidental strain on the cable or liquid ingress at the connector remains a residual risk.	0 0 0
	Measures Currently in place to prevent risk of injury	
	Power supply limited to SELV (= 24 V DC) and CE-compliant low-voltage design. Laptop/USB port remains de-energised until the device enumerates ("power-on last" rule). 4 m custom cable is routed away from walkways and inspected for abrasion before each use. Operator unplugs the scanner before cleaning or changing accessories. Only trained personnel handle electrical connections.	

Potential Rating	Additional Controls Required
Low Risk	No Remedial Actions Entered If there are any reasonably practicable actions which can be taken to reduce the risk associated with this hazard please use the form above to enter them.

Current Rating	Hazard Information	Task Status
Low Risk	⚠️ Slip / Trip / Fall During scanning the user moves around the part while a 4-metre USB or power cable lies on the floor. Poor cable management or cluttered work zones can cause tripping, leading to personal injury or damage to the fragile optical instrument.	0 0 0
	Measures Currently in place to prevent risk of injury	
	Keep the scanning area clear of tools and other trip hazards. Mark the operator's path with floor tape when scanning large objects. Coil and secure excess cable length with Velcro ties.	

Potential Rating	Additional Controls Required
Low Risk	No Remedial Actions Entered If there are any reasonably practicable actions which can be taken to reduce the risk associated with this hazard please use the form above to enter them.

Current Rating	Hazard Information	Task Status
Low Risk 	Ergonomics The scanner weighs roughly 0.9–1.25 kg and is held at arm’s length while the operator performs repetitive sweeping motions. Prolonged use, awkward wrist angles, or over-reaching around large parts may lead to muscle fatigue or cumulative strain injuries in the shoulder, wrist, or lower back.	0 0 0
	Measures Currently in place to prevent risk of injury	
	Alternate hands and schedule short rest breaks every 10 minutes of scanning. Provide an adjustable turntable or part stand to minimise over-reach. Include ergonomic-posture training in user induction.	

Potential Rating	Additional Controls Required
Low Risk 	No Remedial Actions Entered If there are any reasonably practicable actions which can be taken to reduce the risk associated with this hazard please use the form above to enter them.